



Australia's No. 1 Choice for Digital Camera Protection



Brand	Suitable for Models:	Apex AW	Cirrus/Terraclime	D-Pods	Spectrum	Napoli / Luxe	Rezo	Ridge	Tasca
Canon	G7 / G9 / G10 / P'Shot A650is / SX100is / SX 110is	60AW	TLZ 5 / T'clime30	50	50	EDIT 100 (G10)	60 / 50 (G10)	60	30
	IXUS 980 is	20AW	Terraclime 30	20	10		20	10	30
	IXUS 75 / 80is / 85is / 90is	5AW		10	10	10 / Luxe	10/ 15	10	10
	IXUS 860is / 870 is / 960is / PSA1000is	20AW		20	10 / 30(A1000IS)	20 / Luxe	15	10	10 / 30
	IXUS 950is / 970is	10AW		20	10	20 / Luxe	15	10	30
	PowerShot A420 / A430 / A460 / A470	20AW		30	50		30	20	30
	PowerShot A530 / A570is / E1	30AW/20AW(E1)	TLZ 5(A530/570)	30	30	30	50	30	30
	PowerShot A540 / A550 / A560 / A 2000is	30AW	TLZ 5	30	30	30	50	30	30
	PowerShot A630 / A580 / A720is / A590is	60AW	TLZ5 (A630/720)	50/30(720/590)	30		50	60 / 30(720/590)	30
	PowerShot S5is	100AW	TLZ 5			Edit 140		TLZ-10 / 110AW	
	Powershot SX10 is	100AW	Clips 100			Edit 110/120		110 AW	Terraclime 100
	Powershot SX 1 is	110AW	TLZ 15 / 120					TLZ 10 / 110AW	Terraclime 100
	PowerShot TX-1	20AW		20	30	10	15	10	30
Casio	Exilim EX-V7, EX-V8 / EX-Z250 / EX-Z300	10AW		20	10	20	15	10	20
	Exillm EX-Z9/ EX-Z100 / EX-Z85	5AW		20 / 10(EX-Z85)	10	10 / Luxe	15	10	10
	Exilim PRO EX-F1	110AW	TLZ15/120	EX 120 / 140	D-Res 40AW	Nova 1AW	LZ 20/120AW/140AW	Edit 160	
	Exilim EX-Z1050 / EX-Z1200	10AW		10 / 20(Z1200)	10	10 / Luxe	15	10	10
Exilim EX-Z75, Z77 / EX-Z700 / EX-Z80	10AW(5AW Z80)		10	10	5	15	10	20 (10 Z80)	
Fujifilm	Exilim EX-Z5 / EX-Z8 / V7 / V8 / S880	10AW		20	10	10 / 20(V8/S880)	10 / 15(V8 / S880)	10	10 / 20(V8/S880)
	Finepix F480 / F47fd / F31fd / F100fd	20AW		20	30	20	20	10	30
	Finepix A610 / A820 / A825 / A900 / A920	30AW		20	30	20 / Luxe(A850)	20	20	30
	Finepix F50fd / J10,J12,J15 / Z100fd, Z200fd / A850	10AW	Terraclime 10	10 / 20 (A850)	10	20(A850)/10/Luxe	15	10	20
	Finepix J100 / J110W / J120 / J150W / F60fd	10AW		10	10	10 /Luxe	15	10	10
	Finepix J50	20AW		20	30	10	15	10 / 20(J50)	20
	Finepix S5700 / S5800	100AW	TLZ 5		Edit 120		110AW	60	
	Finepix S100FS	120AW	TLZ 15 / 110				110AW		
	Finepix S1000fd	100AW	TLZ 5				60		
	Finepix S65000fd	110AW	TLZ15/110		Edit 120		TLZ10/110AW		
	Finepix S8000fd / S8100fd / S2000 HD	100AW	TLZ 5				TLZ10/110AW	Nova Micro	
	Finepix S9100 / S9500 / S9600	110AW	TLZ15/110		Edit 140		TLZ10/110AW	Nova Micro	
	Finepix Z3 / Z5fd / Z100fd / Z100fd / Z20fd / Z50fd	5AW		10	10	10 / Luxe	10 /15(Z20/50fd)	10	10
Kodak	EasyShare C763, C713, C913, C1013	10AW	Terraclime 10	20	10	20 / 10 / Luxe	15	10	30 / 20 (M1073)
	EasyShare C613 / V1233 / V1253 / Z1085is	20AW	Ridge 30(Z1085is)	30	30	20 / 30(Z1085is)	30 / 20(1233/53)	20/10(1233/53)	30
	EasyShare M1033, M1063, M1073is	10AW	Terraclime 10	20	10	20 / 10 / Luxe	15	10	30 / 20 (M1073)
	EasyShare M763 / M863 / M873 / M883	5AW		20	10	10 / Luxe	15	10	10
	Easyshare M1093is	10AW	Terraclime 10	20	10	10 / Luxe	15	10	20
	EasyShare Z812is / Z1012is / Z D710	100AW	TLZ 5		D-Res 30AW		60 / TLZ 10	60 (Z D710)	Terraclime 50
	Easyshare Z1015is	110AW	100		D-Res 30AW	Terraclime 50	TLZ 10	60	
	Easyshare C813	30AW	Terraclime 10	30	30		50	30	30
	Easyshare Z8612is	60AW	TLZ 5			Terraclime 50	60	60	
	Nikon	Coolpix L10 / L11 / L12 / L14 / L15 / L16 / L18	20AW		30 / 20(L16/18)	10 / 30(L16/18)	20	20	10
Coolpix P5000 / P5100 / P60		20AW		30	50		50	30	30
Coolpix P80		100AW	TLZ5	Terraclime 50	Edit 100/110	D-Res 30AW	TLZ10/110AW		Nova Micro
Coolpix S10 / P6000 GPS		60AW	Terraclime 30	30	50		50	30	
Coolpix S 60		20AW	Terraclime 30	10	30	20	15	10	20
Coolpix S200 / S210 / S600VR		5AW		10	10	5 / Luxe	15	10	10
Coolpix S51/51C / S8 / S52 / S52C / S-610C / S-710		10AW	Terraclime 30	20	10	10 / Luxe	15	10	10 / 20(S8)
Coolpix S560 / S-610		5AW		10	10	10 / Luxe	15	10	10 / 20(S610)
Coolpix S510VR / S700 / S520 / S550VR		5AW		10	10	10 / Luxe	15	10	10/30(S520/550)



Brand	Suitable for Models	Apex AW	Cirrus/Terraclime	D-Pods	Spectrum	Napoli / Luxe	Rezo	Ridge	Tasca
Olympus	FE-170 / FE-270	30AW		30	10	20	20	20	30
	FE-20 / 200 / 290 / 310 / 340 / 350 / 370 / μ1060	20AW	Terraclime 10	20	30 / 10(FE-350)	20	20	10	30/20(FE290/350)
	μ770SW / FE-320 / μ1040	10AW	Terraclime 10	10 / 20(FE-320)	10	10 / Luxe	15	10	10
	FE-230 / FE-240 / FE-250 / FE-280	5AW		10	10	5/10(FE-280)/Luxe	10	10	10
	FE-360	5AW	Terraclime 10	20	10	10 / Luxe	15	10	20
	μ1200 / μ1030SW	20AW	110 (Mju1200)	20	30 / 10(1030SW)	10 / 20(1030SW)	15	10	20
	μ1010 / μ1020	30AW		20	30		20	10	20
	μSW: 720, 725, 775, 790, 795, 850SW, μ1050SW	10AW	Terraclime 50	20	10	20 / Luxe(725SW)	15	10	10
	μ820 / μ 830 / μ1000 / μ840	20AW/10AW(830)		10	30	20 / 10(840)	15	10	30
	SP-550 / SP-560UZ / SP-565UZ	100AW	TLZ 5			D-Res 30AW		TLZ 10	60
SP-570UZ	110AW	100			D-Res 30AW		TLZ 10	60	
Panasonic	Lumix DMC-FX10 / FX12 / FX30 / FX35 / FX37	5AW	Terraclime 10	20	20 / 10 (FX37)	10 / Luxe	15	10	20
	Lumix DMC-FS3 / FS5 / FS20 / FX520	30AW		20	10	20 / Luxe		10	20
	Lumix DMC-FX500 / FX36 / FX38	10AW		20	30	20 / Luxe	15	10	20
	Lumix DMC-FX100 / LS80 / FX150	20AW	Terraclime 10	20	30	20	20	10	20
	Lumix DMC-FZ18	100AW	100			D-Res 40AW		110AW	
	Lumix DMC-FZ50 / DMC-FZ28	110AW	TLZ15/110			Edit 140/110(FZ-28)		120AW/TLZ 20	
	Lumix DMC-FZ8	100AW				Edit 100		TLZ 10	
	Lumix DMC-LX2	60AW	TLZ 5	30	30		50	60	30
	Lumix DMC-LZ6 / LZ7	60AW		20	30		20	20	30
	Lumix DMC-TZ2,3,4,5 / TZ11 / TZ15 / TZ50 / LX3	30AW/20AW(2&3)	Terraclime 30	30	30		30	20	30
Pentax	Optio A10 / A20 / A30 / A40 / S10 / S10S	10AW		10		10 / Luxe	15	10	
	Optio M40 / T30 / M30 / M50	10AW		20	10	10 / 20/Luxe(M50)	20 / 15(M50)	10	10 / 30(M50)
	Optio S7 / S12	5AW		10	10	5 / Luxe	15	10	10
	Optio W10 / W20 / W30	20AW		20		D-Res 8M	20	10	30 / 20(W30)
	Optio Z10 / E50 / E60 / M60 / W60	10AW	Terraclime 30	20	10	20	15	10	10
	Optio E20 / E30 / E40	30AW		30	30	20	20	20	30
Ricoh	Caplio R5 / R6 / R7 / R8 / R10	20AW	Terraclime 30	20	30	20 / (Not R8/R10)	20	10 / 20(R8/R10)	20
	RR 660 / 750 / RX	10AW		20		20	20	10	
	GR Digital II / GR / R50	20AW		30 / 20(R50)	10	20 (R50 Only)	30 / 15(R50)	10	20
	GX 100 / G600 / GX200	60AW	TLZ 5(GX100)	50 (G600)			50 (G600)		30 (G600)
Samsung	Digimax L730, L201	10AW	Terraclime 10	20	10	10 / Luxe	15	10	20
	NV 24HD	20AW		20		Luxe	20	20	30
	D'max S600 / S700 / S800 / S630 / S730	20AW		20	10	20	15	10	30
	Digimax S760 / S860 / NV9 / TL9	10AW	Terraclime 10	20	10	30 / 20 (NV9)	20	10	30
	Digimax S1070	10AW	Terraclime 10	20	10	10 / Luxe	15	10	20
	Digimax i8 / L100 / L110 / L210	5AW		10	10	5 / Luxe	10	10	10
Sony	Cyber-shot DSC-H3 / DSC-H10	60AW	TLZ 5		50				
	Cyber-shot DSC-H7 / H9 / H50	110AW	TLZ 5					TLZ 10 / 110AW	
	C'shot DSC-S650 / S700 / S730 / S800	10AW		20	10	20	20	10	30
	Cyber-shot DSC-W35/W55/W80/W85	10AW		20	10	10 / Luxe	15	10	10
	Cyber-shot DSC-W115 / W125 / W150 / W170	10AW		20	10	10 / Luxe	15	10	30
	Cyber-shot DSC-W110 / W120 / W130	10AW		20	10	10 / Luxe	15	10	10
	DSC-T200 / DSC-W100 / W200 / W300	10AW		20	10	20 / Luxe	15	10	30 (Not T200)
	DSC-T700 / DSC-T77	10AW		10	10	10 / Luxe	10	10	
	DSC-T500	20AW	Terraclime 30	20	30	20	20	10	30
	DSC-T70 / DSCT2 / DSC-T300	5AW/10AW(T300)		10	10	10 / Luxe	15	10	

Note: Lowepro recommended bags are based on published camera dimensions. Customers should always check actual fit for unspecified protrusions.



Lowepro Australia's No. 1 Choice for Digital Video Camera Protection



Brand	Suitable for Models	Apex AW	Cirrus	Clips	D-Res	Edit	Rezo	Other
Canon	DC21 / DC22 / DC210 / DC220 / DC230	100AW		100	200AW	110	110AW	Ridge 60
	DC50 / DC51	100AW		100	200AW	110	110AW	
	DVD DC310 / DC320 / DC330	100AW	100	100		110		
	HG10/20/21 / MD225 / HF10, 11, 100	110AW		100	40AW	110 / 120	110AW	Terraclime 50/100 (inc access's)
	HV10 / HV 20 / HV30 / HR10	110AW	100	100		110/120(HR10)		
	MD120 / MD160 / FS10 / FS11 / FS100	100AW	100(FS Series)	100	220AW	100	110AW	
	XH-A1 / XL-H1	Commercial AW DV						
JVC	EVERIO GZ-HD3, HD5, HD6	120AW		110		110 / 120	50AW	
	EVERIO GZ-HD7			120	50AW	140	170AW	
	EVERIO GZ-MG 135/145/155/505/345H	100AW	TLZ 5	100	220AW	100	110AW	
	EVERIO GZ-MG 330, 335, 365, 465 / MS-100A	60AW	TLZ 5	100		100		
	EVERIO GZ-MG 530, 730 / GZ-HD10, 30, 40	100AW		100		110 / 120+	110AW	
	EVERIO GZ-MG 275 / 575	100AW		100		100 / 120	110AW	
	GR-D750 / 770 / 796	100AW	TLZ 5	100	200AW	100 / 110	110AW	
Panasonic	GR-D850 / GR-D870	100AW		100	220AW	100	110AW	
	HDC DX1	120AW		120	40AW	140	120AW	
	HDC SD1 / SD3 / SD5 / SD9, 932 / HDC-SD100	110AW/100WSD9		100	220AW (Not SD9)	110	110AW	
	HDC-HS9	100AW		100		110	110AW	
	HDC-SX5 / FX5	120AW		120	40AW	110	110AW	
	NV-GS 60 / NV-GS 230	100AW		100		100 / 110	110AW	
	SDR H20 / H250 / H280	100AW		100	220AW	100	110AW	
	SDR H40 / SDR H60	60	100	100		100	60	
	SDR S10 SD PALMCORDER / S74	60AW		100		100		
	SDR SW20 (Waterproof) / SDR-S7	60AW	TLZ5(S7)		8 / 10AW(S7)		30/50(S7)	
	VDR D160	60AW		100	220AW	110	60	
	VDR D310	120AW		110	40AW	110	110AW	
	VDR-D220 / VDR-D50	110/100AW(D50)		110/100(D50)		110 / 120	110AW	
	Samsung	VP-D371WI / DC171WI	100AW		100	200AW	100	110AW
VP-MX10 / VP-D381		100AW		100		100	60	
Sanyo	VPC-CA65	60AW			D-Pods 50		50	Ridge 20
	VPC-HD 1000 / VPC-CG9 / VPC-HD 1010	60AW			D-Res 8		50	
SONY	DCR HC28 / HC38 / HC46 / HC48 / HDR-TG1	60AW	TLZ 5	100		100 / 110	110AW	
	DCR SR42/45/46/62/65/82/85/300 / HC62, HC9	100AW	TLZ 5	100	220AW	100	110AW	
	DCR-DVD 608 / 708 / 808 / 610 / 810	110AW		100		110 / 120	110AW	
	DCR-SR200 / SR300 / HC52	100AW	TLZ 5(HC52)	100		110	110AW	
	HDR-CX7/ SR5/ SR7/SR10/SR11/SR12/CX12	110AW		100		110	110AW	
	HDR-HC3 / HDR-HC5 / HDR-HC7 / HC9 / UX10	110AW		120		110	110AW	
	HDR-UX5 / UX7 / SR1 / UX20	120AW		120	40AW	120	120AW	
	HDR FX1							MagnumAW / NatureTrekker 2

Note: Lowepro recommended bags are based on published camera dimensions. Customers should always check actual fit for unspecified protrusions.

Copyright Maxwell International Australia, 2008

dcw_041108-max

Brand	Suitable for Models	Apex AW	Cirrus	EX Series	D-Res	Nova	Rezo	Other Bags to Consider
Canon	EOS 1000D + 18-55 / 400D + 18-55IS	120AW	TLZ 15/100/120	EX 120 / 140	40AW	1AW / 140AW	TLZ 20/120AW/140AW	Terraclime 100
	EOS 450D + 18-55 / 350D + 18-55IS	120AW	TLZ 15/100/120	EX 120 / 140	40AW	1AW / 140AW	TLZ 20/120AW/140AW	Terraclime 100
	EOS 450D Twin lens kit / 1000D Twin KIT	140AW	140	EX 140/160	2 / 160 / 170AW			Terraclime 100
	EOS 50D / 40D / 30D + 17-85 or 18-200IS z'm		TLZ 15 / 120	EX 180		3AW / 170AW		TLZ 1 / Edit 160
	EOS 5D/5D Mk II + 24-75 or 24-105	140AW		EX180	40AW	3AW / 170AW		Terraclime 100
	EOS 1D / 1DS (All) + 17-55 IS + Pro system	Commercial AW	Slingshot300AW	Vertex 300AW	Primus AW	4AW / 200AW	190AW	Stealth Reporter Shoulder Bags
Fujifilm	Finepix S5 Pro + 17-50 / 17-55 f/2.8		140	EX180	40AW	3AW / 170AW	170AW	Stealth Reporter Series
Leica	Leica V-Lux 1 + 35-420mm	120AW	110	EX160 / 180	40AW	2AW /170AW	120AW	
Nikon	D60 18-55VR / D40+18-55 / D40X 18-55	120AW	TLZ 15 / 110	EX 120	40AW	1AW / 140AW	TLZ 20 / 120AW	
	D60 / D40X / D40 / Twin VR Kits + Flash		140	EX140 / 160		3AW / 160AW		Slingshot 200AW or 300AW
	D300 + 17-55 f/2.8 or D700 + 24-70 f/2.8			EX 180		180 / 200AW	180AW	Stealth Reporter 100AW
	D300 +18-200VR			EX 160		3AW / 170AW	180AW	Stealth R100AW / MinMagAW
	D90 / D80 + 18-135 or 18-200 Tamron / D70	120AW / 140AW	TLZ 25	EX140 / EX160		2AW /170AW	TLZ 20 / 140AW	Terraclime 100
	D200 + 17-55 f/2.8			EX180	50AW	2 / 3 / 160AW	170AW	Terraclime 100
	D3/D700: 14-24, 24-70, 70-200, SB800, Batts.	Commercial AW	Slingshot300AW	Vertex 300AW	Primus AW	4AW / 200AW	190AW	Stealth Reporter Shoulder Bags
	E3 + 14-42 + Typical pro lens/flash kit	Commercial AW	Slingshot300AW	Vertex 300AW	Primus AW	4AW / 200AW	190AW	Stealth Reporter Shoulder Bags
	E-520 / E510 (Evolt E-520/510) + Std Zoom	120AW	TLZ 15	EX 140		Mini AW	110AW	
	E-520 / E510 Twin Lens kit		140	EX140 / EX 160		2 / 3 /160AW		Fastpack 200 / Slingshot 200
Olympus	E-420 / 410 (Evolt E-420/410) + Std Z'm	110-AW	TLZ 15	EX 120 / EX140		Mini AW	110AW	Fastpack 100 backpack
	E-420 / 410 Twin Lens Kit		140	EX 140		2 / 3 / 160AW		Slingshot 100 Backpack
	E-400 + Std Lens	120AW	TLZ 25	EX 120	40AW	1AW / 140AW	TLZ 20 / 120AW	
	Lumix DMC-L10	120AW	TLZ 15 / 110	EX 140 / EX 160	40AW	1AW / 140AW	TLZ 20 / 120AW	
	Lumix DMC-G1 w/14-45 Micro 4/3 Std lens	120AW	TLZ-15 / 110	Terraclime100	TL Zm Mini	Mini AW, 140AW	TLZ 10	Slingshot 100 AW Backpack
	Lumix DMC-G1 Twin Kit (14-45/45-200)	140AW		Terraclime100		140AW	140AW	Slingshot 200 AW backpack
	Lumix DMC-FZ50	110AW	TLZ 15 / 110	EX 120	40AW	1AW / 140AW	TLZ 20 / 120AW	Edit 140
	Lumix DMC-L1	120AW	TLZ 15 / 110	EX 140	40AW	1AW / 140AW	TLZ 20 / 120AW	Stealth Reporter 100
Pentax	K200D/100D S / K20D/K10D + Std Zm	140AW	TLZ 15/100/110	EX 120	40AW	1AW / 140AW	TLZ 20 / 140AW	Edit 140
	K200D/K20D/K100D/K10D Twin lens kit	140AW	140	EX 160	Terraclime 100	1AW / 140AW	140AW	Slingshot 200 AW
	K2000 / Km + short zoom	120AW	TLZ15 / 110	Terraclime 30		160AW	TLZ 20 / 120AW	Slingshot 100AW/200AW
Samsung	GX-10 + Std Zoom Lens	140AW	TLZ 25 /120	EX 120	40AW	1AW / 140AW	140AW	Edit 140
	Sony α	Alpha α 200/ α 100 + Std Zoom Lens	140AW	140	EX 120 / EX 140	40AW	Mini AW	120AW / TLZ20
Sony α	Alpha α 200 / α 100 Twin Lens Kit	140AW	140	EX 140 / EX 160		2AW /170AW		Flipside series
	Alpha α 700 + Std Zoom		120	EX 160	40AW	2AW /170AW	180AW	Edit 160
	Alpha α 700 Twin Lens Kit		140	EX 160 / EX 180		2 / 3 /160AW		Slingshot 200AW
	Alpha α 900 + 16-35mm + 24-70 f/2.8 + flash	160AW	Slingshot 300AW	EX 180		180 / 170AW	170AW	Stealth Reporter Shoulder Bags
	Alpha α 350 / α 300 + Std Lens	120AW	TLZ 15 / 120	EX 160 / EX 180	40AW	140/160AW	120AW / TLZ20	Edit 160

Note: Lowepro recommended bags are based on published camera dimensions. Customers should always check actual fit for unspecified protrusions.