Camera and Lenses compatibility chart

This document is a reference for compatibility of nikon DX-format digital SLR cameras with interchangeable lenses. Focus, Mode and Metering compatibility is provided for each combination.

For information on the difference between non Ai, Ai and Ais lenses
http://nikoneurope-en.custhelp.com/cgi-bin/nikoneurope_en.cfg/php/enduser/std_adp.php?p_faqid=1160

For information on the difference between non AF-D and AF-G lenses visit
http://nikoneurope-en.custhelp.com/cgi-bin/nikoneurope_en.cfg/php/enduser/std_adp.php?p_faqid=12089

		Camera *3 / Lens	D40/40X						D80/D70/70S/D50						D100							D200/D2 Series							D1 Series					
			Focus		Mode		Metering		Focus		Mode		Metering		Focus		Mode		Metering			Focus		Mode		Metering			Focus		Mode		Metering		
							Matrix						Matrix						Matrix							Matrix						Matrix		
	Lens type	Product Name	AF	M (with electronic range finder)	Digital Vari Program, P,S,A	M	3D-RGB	RGB	Center-weighted/Spot	AF	M (with electronic range finder)	Digital Vari Program, P,S,A	M	3D-RGB	RGB	Center-weighted/Spot	AF	M (with electronic range finder)	P S A	M	3D	Ten-Segment	Center-weighted/Spot	AF	M (with electronic range finder)	P S A	M	3D-RGB	RGB	Center-weighted/Spot	AF	M (with electronic range finder)	P S	A M	3D-RGB	RGB	Center-weighted/Spot
CPU lenses *2	Type D lenses	AF Nikkor 14mm f/2.8D ED	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Nikkor 18mm f/2.8D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Fisheye-Nikkor 16mm f/2.8D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Nikkor 20mm f/2.8D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Nikkor 24mm f/2.8D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Nikkor 28mm f/1.4D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Nikkor 28mm f/2.8D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Nikkor 35mm f/2D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Nikkor 50mm f/1.4D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Nikkor 50mm f/1.8D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Micro-Nikkor 60mm f/2.8D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Nikkor 85mm f/1.4D IF	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Nikkor 85mm f/1.8D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF DC-Nikkor 105mm f/2D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Micro-Nikkor 105mm f/2.8D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF DC-Nikkor 135mm f/2D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Nikkor 180mm f/2.8D IF-ED	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Micro-Nikkor 200mm f/4D IF-ED	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 18-35mm f/3.5-4.5D IF-ED	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 20-35mm f/2.8D IF	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 24-50mm F3.3-4.5D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 24-85mm f/2.8-4.4D IF	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 24-120mm f/3.5-5.6D IF	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 28-105mm f/3.5-4.5D IF	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 28-70mm f/3.5-4.5D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 28-80mm f/3.5-5.6D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 28-200mm f/3.5-5.6D IF	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 35-70mm f/2.8D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 35-80mm f/4-5.6D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 35-105mm f/3.5-4.5D IF	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Micro Nikkor 70-180mm f/4.5-f/5.6D ED	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 70-210mm f/4-5.6D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 70-300mm f/4-5.6D ED	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 75-240mm f/4.5-5.6D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 80-200mm f/2.8D ED	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 80-200mm f/4.5-5.6D	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF VR Zoom-Nikkor 80-400mm f/4.5-5.6D IF-ED	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
	Type G lenses	AF Zoom-Nikkor 70-300mm f/4-5.6G	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 28-80mm F3.3-5.6G	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 28-200mm f/3.5-5.6G IF-ED	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF Zoom-Nikkor 28-100mm f/3.5-5.6G	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
	AF-I lenses	AF-I Nikkor 300mm f/2.8D IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-I Nikkor 400mm f/2.8D IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-I Nikkor 500mm f/4D IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-I Nikkor 600mm f/4D IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
	AF-S lenses	AF-S VR Micro-Nikkor 105mm f/2.8G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S VR Nikkor 200mm f/2G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Nikkor 300mm f/2.8D ED-IF	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Nikkor 300mm f/2.8D II ED-IF	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Nikkor 300mm f/4D ED-IF	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S VR Nikkor 300mm f/2.8G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Nikkor 400mm f/2.8D ED-IF	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Nikkor 400mm f/2.8D II ED-IF	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Nikkor 500mm f/4D IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Nikkor 500mm f/4D II IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Nikkor 600mm f/4D IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Nikkor 600mm f/4D II IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Zoom-Nikkor 17-35mm f/2.8D IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Zoom-Nikkor 24-85mm f/3.5-4.5G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S VR Zoom-Nikkor 24-120mm f/3.5-5.6G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Zoom-Nikkor 28-70mm f/2.8D IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S VR Zoom-Nikkor 70-200mm f/2.8G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S VR Zoom-Nikkor 70-300mm f/4.5-5.6G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S Zoom-Nikkor 80-200mm f/2.8D IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S VR Zoom-Nikkor 200-400mm f/4G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
	DX Nikkor lenses	AF DX Fisheye-Nikkor 10.5mm f/2.8G ED	–	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S DX Zoom-Nikkor 12-24mm f/4G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S DX Zoom-Nikkor 17-55mm f/2.8G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S DX Zoom-Nikkor 18-55mm f/3.5-5.6G ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S DX Zoom-Nikkor 18-55mm f/3.5-5.6G II ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S DX Zoom-Nikkor 18-70mm f/3.5-4.5G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S DX Zoom-Nikkor 18-135mm f/3.5-5.6G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S DX VR Zoom-Nikkor 18-200mm f/3.5-5.6G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
		AF-S DX Zoom-Nikkor 55-200mm f/4-5.6G IF-ED	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○
	PC Micro-Nikkor lens	PC Micro-Nikkor 85mm f/2.8D	–	○*5	–	○	○	–	○	–	○*5	–	○	○	–	○	–	○*5	–	○	○	–	○	–	○*5	–	○*16	○	–	○	–	○*5	–	○*16	○	–	○
	AF-S/AF-I Teleconverters *6	AF-I Teleconverter TC-14E	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○
		AF-S Teleconverter TC-14E II	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○
		AF-S Teleconverter TC-17E II	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○
		AF-I Teleconverter TC-20E	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○
		AF-S Teleconverter TC-20E II	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○	○*7	○*7	○	○	○	–	○
	Other AF Nikkor lenses (except lenses for F3AF)	AF Nikkor 20mm f/2.8	–	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○
		AF Nikkor 24mm f/2.8	–	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○	○	○	○	○	–	○	○

		Camera *3 / Lens	D40/40X						D80/D70/70S/D50						D100						D200/D2 Series						D1 Series					
			Focus		Mode		Metering		Focus		Mode		Metering		Focus		Mode		Metering		Focus		Mode		Metering		Focus		Mode		Metering	
							Matrix						Matrix						Matrix						Matrix						Matrix	
			AF	M (with electronic range finder)	Digital Vari Program, P,S,A	M	3D-RGB	RGB	Center-weighted/Spot	AF	M (with electronic range finder)	Digital Vari Program, P,S,A	M	3D-RGB	RGB	Center-weighted/Spot	AF	M (with electronic range finder)	P S A	M	3D	Ten-Segment	Center-weighted/Spot	AF	M (with electronic range finder)	P S A	M	3D-RGB	RGB	Center-weighted/Spot	AF	M (with electronic range finder)	P S	A M	3D-RGB	RGB	Center-weighted/Spot
		Product Name																																	
	Other AF Nikkor lenses (except lenses for F3AF)	AF Nikkor 28mm f/2.8	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Nikkor 35mm f/2	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Nikkor 50mm f/1.4	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Nikkor 50mm f/1.8	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Micro-Nikkor 55mm f/2.8	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Nikkor 85mm f/1.8	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Micro-Nikkor 105mm f/2.8	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF DC-Nikkor 135mm f/2	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Nikkor 180mm f/2.8 IF-ED	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Nikkor 300mm f/2.8 IF-ED	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Nikkor 300mm f/4 IF-ED	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Zoom-Nikkor 24-50mm F3.3-4.5	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Zoom-Nikkor 28-70mm f/3.5-4.5	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Zoom-Nikkor 28-85mm f/3.5-4.5	—	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○
		AF Zoom-Nikkor 35-70mm f/2.8	—	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○
		AF Zoom-Nikkor 35-70mm F3.3-4.5	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Zoom-Nikkor 35-105mm f/3.5-4.5	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Zoom-Nikkor 35-135mm f/3.5-4.5	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Zoom-Nikkor 70-210mm f/4	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Zoom-Nikkor 70-210mm f/4-5.6	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Zoom-Nikkor 75-300mm f/4.5-5.6	—	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	○	—	○	○	○	○	○	—	○	○	○	○	○	—	○	○
		AF Zoom-Nikkor 80-200mm f/2.8 ED	—	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○	○*8	○*8	○	○	—	○	○
	AI-P Nikkor lenses	Zoom-Nikkor 1200-1700mm f/5.6-8P IF-ED	—	△	○	○	—	○	○	—	△	○	○	—	○	○	—	△	○	○	—	○	○	—	△	○	○	—	○	○	—	△	○	○	—	○	○
		Nikkor 45mm f/2.8P	—	○	○	○	—	○	○	—	○	○	○	—	○	○	—	○	○	○	—	○	○	—	○	○	○	—	○	○	—	○	○	○	—	○	○
		Nikkor 500mm f/4P IF-ED	—	○	○	○	—	○	○	—	○	○	○	—	○	○	—	○	○	○	—	○	○	—	○	○	○	—	○	○	—	○	○	○	—	○	○
Non-CPU lenses *10	AI Nikkor lenses, Nikon Series E lenses, AI modified Nikkor lenses	Fisheye-Nikkor 6mm f/2.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Fisheye-Nikkor 8mm f/2.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 13mm f/5.6	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 15mm f/3.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 15mm f/5.6	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Fisheye-Nikkor 16mm f/2.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Fisheye-Nikkor 16mm f/3.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 18mm f/4	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 18mm f/3.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 20mm f/2.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 20mm f/3.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 20mm f/4	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 24mm f/2	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 24mm f/2.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 28mm f/2	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 28mm f/2.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 28mm f/3.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 35mm f/1.4	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 35mm f/2	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 35mm f/2.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 50mm f/1.2	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 50mm f/1.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 50mm f/1.4	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 50mm f/2	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 55mm f/1.2	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Micro-Nikkor 55mm f/2.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Micro-Nikkor 55mm f/3.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Noct-Nikkor 58mm f/1.2	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 85mm f/1.4	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 85mm f/2	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 105mm f/1.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 105mm f/2.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Micro-Nikkor 105mm f/2.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Micro-Nikkor 105mm f/4	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		UV-Nikkor 105mm f/4.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 135mm f/2	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 135mm f/2.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 135mm f/3.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 180mm f/2.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 180mm f/2.8 ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 200mm f/2 IF-ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 200mm f/4	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Micro-Nikkor 200mm f/4 IF	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 300mm f/2 IF-ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 300mm f/2.8 IF-ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 300mm f/4.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 300mm f/4.5 ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 300mm f/4.5 IF-ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 400mm f/2.8 IF-ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 400mm f/3.5 IF-ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 400mm f/5.6 ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 400mm f/5.6 IF-ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 600mm f/4 IF-ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 600mm f/5.6S IF-ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 800mm f/5.6 IF-ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Nikkor 800mm f/8 IF	—	—	—	○*11	—	—	—	—	—	—	○*11	—	—	—	—	—	—	○*11	—	—	—	—	—	—	○*19	—	○*20	○*21	—	—	—	○	—	—	○
		Nikkor 1200mm f/11 IF-ED	—	—	—	○*11	—	—	—	—	—	—	○*11	—	—	—	—	—	—	○*11	—	—	—	—	—	—	○*19	—	○*20	○*21	—	—	—	○	—	—	○
		Zoom-Nikkor 25-50mm f/4	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 28-45mm f/4.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 28-50mm f/3.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 28-85mm f/3.5-4.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 35-70mm f/3.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 35-70mm f/3.3-4.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 35-70mm f/3.5-4.8	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 35-105mm f/3.5-4.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 35-135mm f/3.5-4.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 35-200mm f/3.5-4.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 43-86mm f/3.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 50-135mm f/3.5	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○
		Zoom-Nikkor 50-300mm f/4.5 ED	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*11	—	—	—	—	○	—	○*19	—	○*20	○*21	—	○	—	○	—	—	○

		Camera ＊3 / Lens	D40/40X							D80/D70/70S/D50							D100							D200/D2 Series							D1 Series						
			Focus		Mode		Metering			Focus		Mode		Metering			Focus		Mode		Metering			Focus		Mode		Metering			Focus		Mode		Metering		
							Matrix							Matrix							Matrix							Matrix							Matrix		
			AF	M (with electronic range finder)	Digital Vari Program, P,S,A	M	3D-RGB	RGB	Center-weighted/ Spot	AF	M (with electronic range finder)	Digital Vari Program, P,S,A	M	3D-RGB	RGB	Center-weighted/Spot	AF	M (with electronic range finder)	P S A	M	3D	Ten-Segment	Center-weighted/ Spot	AF	M (with electronic range finder)	P S A	M	3D-RGB	RGB	Center-weighted/ Spot	AF	M (with electronic range finder)	P S	A M	3D-RGB	RGB	Center-weighted/ Spot
		Product Name																																			
		Zoom-Nikkor 70-210mm f/4.5-5.6	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Zoom-Nikkor 80-200mm f/2.8 ED ∗17	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Zoom-Nikkor 80-200mm f/4	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Zoom-Nikkor 80-200mm f/4.5	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Zoom-Nikkor 100-300mm f/5.6	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Zoom-Nikkor 180-600mm f/8 ED	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗19	—	○∗20	○∗21	—	—	—	○	—	—	○
		Zoom-Nikkor 200-400mm f/4 ED ∗18	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Zoom-Nikkor 200-600mm f/9.5	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗19	—	○∗20	○∗21	—	—	—	○	—	—	○
		Zoom-Nikkor 360-1200mm f/11ED	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗19	—	○∗20	○∗21	—	—	—	○	—	—	○
		Nikon Series E 28mm f/2.8	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Nikon Series E 35mm f/2.5	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Nikon Series E 50mm f/1.8	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Nikon Series E 100mm f/2.8	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Nikon Series E 135mm f/2.8	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Nikon Series E 36-72mm f/3.5	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Nikon Series E 70-210mm f/4	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
		Nikon Series E 75-150mm f/3.5	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗11	—	—	—	—	○	—	○∗19	—	○∗20	○∗21	—	○	—	○	—	—	○
	Medical-Nikkor lenses	Medical-Nikkor 120 f/4 (IF)	—	○	—	○∗12	—	—	—	—	○	—	○∗13	—	—	—	—	○	—	○∗15	—	—	—	—	○	—	○∗22	—	—	—	—	○	—	○∗27	—	—	—
	Reflex-Nikkor lenses	Reflex-Nikkor 500mm f/5	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗19	—	—	○∗21	—	—	—	○	—	—	○
		Reflex-Nikkor 500mm f/8	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗19	—	—	○∗21	—	—	—	○	—	—	○
		Reflex-Nikkor 1000mm f/6.3	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗19	—	—	○∗21	—	—	—	○	—	—	○
		Reflex-Nikkor 1000mm f/11	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗19	—	—	○∗21	—	—	—	○	—	—	○
		Reflex-Nikkor 2000mm f/11	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗11	—	—	—	—	—	—	○∗19	—	—	○∗21	—	—	—	○	—	—	○
	PC-Nikkor lenses	PC-Nikkor 28mm f/3.5	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗23	—	—	○	—	○∗5	—	○∗23	—	—	○
		PC-Nikkor 28mm f/4	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗23	—	—	○	—	○∗5	—	○∗23	—	—	○
		PC-Nikkor 35mm f/2.8	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗23	—	—	○	—	○∗5	—	○∗23	—	—	○
		PC-Nikkor 35mm f/3.5	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗11	—	—	—	—	○∗5	—	○∗23	—	—	○	—	○∗5	—	○∗23	—	—	○
	AI-type Teleconverters ∗24	Teleconverter TC-14A, TC-14B, TC-14C	—	○∗7	—	○∗11	—	—	—	—	○∗7	—	○∗11	—	—	—	—	○∗7	—	○∗11	—	—	—	—	○∗7	—	○∗19	—	○∗20	○∗21	—	○∗7	—	○	—	—	○
		Teleconverter TC-14, TC-200, TC-300	—	○∗7	—	○∗11	—	—	—	—	○∗7	—	○∗11	—	—	—	—	○∗7	—	○∗11	—	—	—	—	○∗7	—	○∗19	—	○∗20	○∗21	—	○∗7	—	○	—	—	○
		Teleconverter TC-201, TC-301	—	○∗7	—	○∗11	—	—	—	—	○∗7	—	○∗11	—	—	—	—	○∗7	—	○∗11	—	—	—	—	○∗7	—	○∗19	—	○∗20	○∗21	—	○∗7	—	○	—	—	○
	AF Teleconverter	AF Teleconverter TC-16A	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○∗28	○∗7	—	○∗19	—	○∗20	○∗21	—	○∗7	—	—	—	—	—
	Bellows Focusing Attachment ∗14、∗25	Bellows Focusing Attachment PB-6	—	○∗9	—	○∗11	—	—	—	—	○∗9	—	○∗11	—	—	—	—	○∗9	—	○∗11	—	—	—	—	—	—	○∗9	—	○∗26	—	—	—	○	—	○∗9	—	○∗15	—	—	○
	Auto Extension Rings	Auto Extension Rings PK-11A, 12, 13, and PN-11	—	○∗9	—	○∗11	—	—	—	—	○∗9	—	○∗11	—	—	—	—	○∗9	—	○∗11	—	—	—	—	—	—	○∗9	—	○∗19	—	—	○	—	—	○∗9	—	○	—	—	○
Other	Fieldscope Attachment	Fieldscope Digital SLR Camera Attachment FSA-L1 *29	—	—	○∗30	○	—	—	○	—	—	○∗30	○	—	—	○	—	×	○∗30	○	—	—	○	—	—	—	○∗30	—	−∗31	○	—	—	—	○∗30	—	—	○
		Photographic Attachment for Fieldscope	—	—	—	○	—	—	○	—	—	—	○	—	—	○	—	×	—	○	—	—	○	—	—	—	○	—	—	○	—	—	—	○	—	—	○

○: Compatible - :Not compatible △ : Electronic rangefinder not possible at 1700mm setting

*1 Spot metering meters selected focus area.
*2 IX-Nikkor lenses can not be used.
*3 Vibration Reduction (VR) supported with VR lenses.
*4 The camera's exposure metering and flash control systems do not work properly when shifting and/or tilting the lens, or when an aperture other than the maximum aperture is used.
*5 Electronic rangefinder can not be used with shifting or tilting.
*6 Some lenses can not be used. See Teleconverter user manual for details.
*7 With maximum effective aperture of f/5.6 or faster.
*8 When focusing at minimum focus distance with these lenses at maximum zoom, electronic rangefinder may be displayed when image on matte screen in viewfinder is not in focus. Adjust focus manually until image in viewfinder is in focus.
*9 With maximum aperture of f/5.6 or faster.
*10 Some lenses can not be used (see above).
*11 Camera exposure meter can not be used.
*12 Can be used at shutter speeds slower than 1/125 s, but camera exposure meter can not be used.
*13 D80 can be used at shutter speeds slower than 1/60 s, D70/70S/D50 can be used at shutter speeds slower than 1/125 s. But both camera exposure meters can not be used.
*14 D40/D40X, D80/D70/70S/D50, and D100: Attach in vertical orientation (can be used in horizontal orientationonce attached).
*15 Can be used in manual exposure [M] mode at shutter speeds slower than 1/180 s, but camera exposure meter can not be used.
*16 Manual exposure [M] mode only.
*17 Range of rotation for this lens tripod mount limited by D200 camera body.
*18 Filters can not be exchanged while the lens is mounted on D200.
*19 If maximum aperture is specified using [Non-CPU Lens Data option] in shooting menu, aperture value will be displayed in viewfinder and control panel.
*20 Can be used only if lens focal length and maximum aperture are specified using [Non-CPU Lens Data option] in shooting menu. Use spot or center-weighted metering if desired results are not achieved.
*21 For improved precision, specify lens focal length and maximum aperture using [Non-CPU Lens Data option] in shooting menu.
*22 Can be used at in manual exposure modes at shutter speeds slower than 1/125 s. If maximum aperture is specified using [Non-CPU Lens Data option] in shooting menu, aperture value will be displayed in viewfinder and control panel.
*23 Exposure determined by presetting lens aperture.
*24 D200, D1-series and D2-series: Exposure compensation required when used with 28–85mm f/3.5–4.5, 35–105mm f/3.5–4.5, 35–135mm /3.5–4.5, or AF-S 80–200mm f/2.8D. See Teleconverter user manual for details.
*25 D200, D1-series and D2-series: Requires Auto Extension Ring PK-12 or PK-13. Depending on the camera position Nikon Bellows/Rail Spacer PB-6D is required.
*26 Use preset aperture. In exposure mode [A], set aperture using focusing attachment before determining exposure and taking photograph.
*27 Can be used at in manual exposure modes at shutter speeds slower than 1/125 s.
*28 D2-series: Can be used with maximum effective aperture of f/5.6 or faster. D200: Can not be used.
*29 Focal length varies according to the attached Fieldscope.
Fieldscope ED82/ED82 A: 1000mm f/13,
Fieldscope ED78/ED78 A: 1000mm f/13,
Fieldscope III/III A/II series/I : 800mm f/13,
Fieldscope ED III/ED III A/ED II series/ED: 800mm f/13.
The picture angle of 35mm format SLR cameras differs from that of Nikon DX-format digital SLR cameras due to the difference in the size of captured images. 35mm equivalent focal length is 1.5x of the focal length of the lens used.
*30 Aperture-priority auto exposure [A] mode only.
*31 D2-series: Can be used but D200: Can not be used.

The following accessories and non-CPU lenses can NOT be used:

- Non-AI lenses
- Lenses that require the Focusing Unit AU-1 (400 mm f/4.5, 600 mm f/5.6, 800 mm f/8, 1200 mm f/11)
- Fisheye-Nikkor (6 mm f/5.6, 8 mm f/8, OP 10 mm f/5.6)
- NIKKOR-O 2.1cm f/4
- Extension Ring K2
- Zoom-Nikkor ED 180–600 mm f/8 (Serial No. 174041–174180)
- Zoom-Nikkor ED 360–1200 mm f/11 (Serial No. 174031–174127)
- Zoom-Nikkor 200–600 mm f/9.5 (Serial No. 280001–300490)
- AF Nikkor lenses for the F3AF (AF 80 mm f/2.8, AF 200 mm f/3.5, AF Teleconverter TC-16)
- PC-Nikkor 28 mm f/4 (Serial No. 180900 or earlier)
- PC-Nikkor 35 mm f/2.8 (Serial No. 851001–906200)
- PC-Nikkor 35 mm f/3.5 (old type)
- Reflex-Nikkor 1000 mm f/6.3 (old type)
- Reflex-Nikkor 1000 mm f/11 (Serial No. 142361–143000
- Reflex-Nikkor 2000 mm f/11 (Serial No. 200111–200310)